

The new tank dishwashers:
Top-class cleaning results combined with short cycles



Spotless glassware.
Perfectly clean crockery.
Sparkling cutlery.

Tough on dirt, gentle on loads



Spotless glassware, perfectly clean crockery and sparkling cutlery – top-flight hospitality is visible at a glance. But the new tank dishwashers from Miele Professional inspire by more than the first-class results they produce. With their short cycles, their sparing use of water and electricity and their gentle wash action, these new products are set to become the top-performing newcomers in hotels, restaurants, bars and cafes.

Strong and adaptable

Tank dishwashers come into their own wherever large amounts of tableware need to be washed in a short space of time. Their insatiable appetite for hard work is now about to be taken to the next level by a new model generation from Miele Professional. Spray arms ensuring full surface coverage and the close monitoring of the condition of the wash liquor guarantees excellent efficiency, even in non-stop use. Load-specific programmes, variable pump pressure and a smooth gentle-start mechanism adapt programmes perfectly to the needs of workaday life in a commercial environment.

Capacities to meet all requirements

The new tank dishwashers offer right-sized capacities for a wide range of applications and baskets for the thorough cleaning of all types of loads. Thanks to their concise and easily visible touch display, these machines are easy to operate without mistakes even under rush-hour conditions.

Miele advantages worth their weight in gold



Perfect dishwashing results in all situations

The new tank dishwashers from Miele Professional feature specific programmes for all load types and degrees of soiling. All the key parameters, e.g. cycle times, temperatures and spray pressure, are carefully tuned before leaving the factory and can be further customised on site - with the result that delicate champagne flutes are cleaned just as gently and reliably as plates with dried-on food residue.



Excellent user convenience

To speed up and simplify everyday operation, the touch display only shows relevant information and symbols during a running programme. And it offers the ultimate in user convenience: The most frequently used programmes can be launched fast and simply, while the colour-change indicator provides up-to-the-minute information on programme progress and machine status.



Wide range of dispensing options

Whatever the situation on site: The new tank dishwashers are geared to the best possible dispensing method. The range with its various models comprises versions with integrated dispenser pumps and siphons for external canisters to models with integrated tanks and dispenser pumps - ideal for kitchens without the space for storing canisters.



Highly economical

The new tank dishwashers from Miele Professional combine high throughput capacity with superb efficiency. Even in the standard programmes, water, electricity and detergent is used extremely sparingly; consumption is reduced to a bare minimum in the Eco cycle. The high-quality design of these machines also means they require less maintenance and last longer, making them the products of choice for discerning clients with a view to their economic credentials.

Strong, reliable, efficient:
The new tank dishwashers
from Miele Professional







PG 8164

BRILLIANTcompact**Commercial tank dishwashers****PG 8164**

Max. theoretical capacity [baskets/h]	80
Shortest programme cycle [seconds]	45
Max. water circulation capacity: [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	Optional
Integrated water softening (WES)	-
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	725-760/460/617
Basket dimensions [mm]	400 x 400
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	7.9/3.2

PG 8164

- Glass washer with tank system
- Perfect for behind-the-counter use

Plus

- Shortest cycle: 45 seconds
- Max. theoretic capacity: 1.600 glasses/h
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Load-specific programmes
- Freestanding unit with lid, can be built under



PG 8165

UNIVERSALcompact**Commercial tank dishwashers**

	PG 8165
Max. theoretical capacity [baskets/h]	66 (glass programme), 49 (plate programme)
Shortest programme cycle [seconds]	55 (glass programme), 74 (plate programme)
Max. water circulation capacity: [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	Optional
Integrated water softening (WES)	-
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	725-760/600/617
Basket dimensions [mm]	500 x 500/500 x 530
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	7.9/3.2

PG 8165

- Reduced-height tank washer
- Perfect for behind-the-counter use
- **Plus**
- Shortest cycle: 55 seconds
- Max. theoretical capacity: 3234 glasses/h or 882 plates/h
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Load-specific programmes
- Freestanding unit with lid, can be built under



Commercial tank dishwashers	PG 8166
Max. theoretical capacity [baskets/h]	66
Shortest programme cycle [seconds]	55
Max. water circulation capacity: [l/min]	200
Integrated tanks for detergent and rinse aid (DOS)	Optional
Integrated water softening (WES)	Optional
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	820–855/600/617
Basket dimensions [mm]	500 x 500/500 x 530
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	7.9/3.2

PG 8166

- Tank dishwasher

Plus

- Shortest cycle: 55 seconds
- Max. theoretical capacity: 1188 plates/h
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Optional: BASIC version without dispensing equipment
- Load-specific programmes
- Freestanding unit with lid, can be built under



PG 8169

UNIVERSALplus**Commercial tank dishwashers****PG 8169**

Max. theoretical capacity [baskets/h]	66
Shortest programme cycle [seconds]	55
Max. water circulation capacity: [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	–
Integrated water softening (WES)	–
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	820–855/600/651
Basket dimensions [mm]	500 x 500/500 x 530/500 x 540
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	7.9/3.2

PG 8169

- Tank dishwasher and deeper chamber
- Particularly suited to the cleaning of trays with crates

Plus

- Shortest cycle: 55 seconds
- Max. theoretical capacity: 1188 plates/h
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Load-specific programmes
- Freestanding unit with lid, can be built under



Accessories from Miele Professional – for optimum system performance

Miele Professional stands for high-quality dishwashers with innovative process technology. But Miele's renowned quality is also reflected in a comprehensive range of accessories guaranteeing even simpler, even faster and even more efficient dishwashing. Carefully formulated detergents and rinse aid complete the offer to make up a unique system: System4Shine from Miele Professional.



Baskets and inserts

Accessories from Miele Professional comprise a wide range of baskets and inserts which perfectly accommodate all types of loads for optimum cleaning.

- Baskets and basket sets for glassware
- Baskets and holders for cutlery
- Baskets for plates and cups
- Bistro and multi-purpose baskets
- Baskets and carriers for trays

Further accessories

- Open/box plinths in various heights
- Drip trays
- Steam protection sets
- CN rear panel
- Water softener, demineralisation cartridges



ProCare Shine

ProCare Shine, a completely new range of detergents was developed from the outset for use in Miele dishwashers. With their finely tuned ingredients, these products form the bedrock of professional and economic crockery care.

- Alkaline and mildly alkaline liquid detergent
- Rinse aid
- Reactivation salt

Miele Co. Ltd
Fairacres
Marcham Road
Abingdon
Oxon, OX14 1TW

miele-professional@miele.co.uk
www.miele-professional.co.uk

Tel.: 0845 330 3618

Forever Better

Since 1899, Miele - a family-run company - has subscribed to a clear corporate philosophy condensed into the two words 'Forever better'. This overarching claim is the foundation of Miele's proverbial quality and sustainability and the power of innovation of a brand 'Made in Germany'. A brand promise which gives commercial users the certainty of having chosen the right product.

Award-winning

Uncompromising product reliability and service dependability is the reason why customers have repeatedly voted Miele the best and most trustworthy brand. Coveted awards such as the MX Award, the iF and reddot Design Awards and the German Sustainability Prize endorse the outstanding position Miele commands with respect to design, quality management and the conservation of valuable resources.

Proficient

Miele Professional has been developing and manufacturing a broad range of high-quality laundry machines, dishwashers, washer-disinfectors and sterilisers for decades. Carefully selected accessories, comprehensive advisory services and a Miele service department which guarantees a quick response ensures that machines perform to satisfaction and offer the ultimate in performance and efficiency.